

NOTE:

- 1. SUPPORT PIPE/BASE PLATE ASSEMBLY TO BE HOT DIP GALVANIZED (DOUBLE DIP) AFTER WELDING.
- 2. FLANGE SUPPORTS ARE NOT INTENDED FOR THRUST RESTRAINT.
- 3. CONTRACTOR CAN USE STAINLESS STEEL EPOXY WEDGE ANCHORS OR STAINLESS STEEL ANCHORS (INSTALLED POST-INSTALLATION) WITH DEPUTY INSPECTION IN LIEU OF "J" ANCHOR BOLTS.



